



#### NOTES

1. ESTABLISH TEMPORARY EROSION CONTROL AT LIMIT OF WORK UNLESS INDICATED OTHERWISE.
2. INSTALL WITH SILT FENCE ON WORK SIDE OF SUPPORT STAKES.

FIGURE 18  
TYPICAL SILT FENCE/HAYBALE  
EROSION CONTROL BARRIER  
NORTHEAST RELIABILITY  
INTERCONNECT PROJECT